

HDX294

Specialised Ultrasonic Cleaning System

The HDX294 is a large ultrasonic cleaning system, ideal for medical device manufacturers, pharmaceutical and other precision equipment industries.

The 316 grade 2mm stainless steel tank offers durability, whilst the radius corners facilitate easy cleaning of the ultrasonic cleaning system.

With a simple On/Off switch at the front of the machine, the HDX294 is controlled by an external wall mounted generator for ease of serviceability.



The programmable control software allows the timer to be set at up to 80 minutes and temperature to be set at up to 80°C.

Standard Features:

- Radius corners within the tank
- External wall mounted generator with programmable software
- *Frequency Leap* Technology
- Fluid level sensor
- Stainless steel lid and basket
- Lockable castors
- 3 year warranty

HDX294

294Litre Ultrasonic Cleaning System

Construction Case	304 Stainless Steel
Construction Tank	316 Stainless Steel (2mm)
Control	Digital (Separate Generator) 7 Day Timer
Overall Dimensions on castor wheels	880 x 880 x 1020mm (WxDxH)
Tank Dimensions	700 x 700 x 700mm (WxDxH)
Basket Dimensions	685 x 685 x 665mm (WxDxH)
Maximum Capacity	343Litres
Working Capacity	294Litres
Ultrasonic Power	3000W RMS 6000W Peak to Peak
Ultrasonic Power (per litre)	10.2W/Litre
Operating Frequency	30 - 40KHz
Maximum Heating Capacity	Ambient - 80°C
Heater Power	4000W
Timer	0 - 80 minutes
Mains Connection	220 - 240V Single Phase + N + E (32A supply)
Drain Outlet	1.5" Stainless steel Lockable drain valve
Lid	304 Stainless Steel
Basket	316 Stainless Steel
Warranty	3 Years

Product code: F0044301 (January 2015)



Eastgate Business Park
Wentloog Avenue
Cardiff CF3 2EY
United Kingdom

Tel: +44 (0) 845 330 4236
Fax: +44 (0) 845 330 4231
Email: admin@ultrawave.co.uk
Web: www.ultrawave.co.uk