

# IND145D

## 145Litre Ultrasonic Cleaner

The **IND145D** is an Industrial grade ultrasonic cleaner for cleaning and processing larger components. Combining high performance transducers and a robust stainless steel tank, this 145Litre tank delivers excellent reliable performance across a diverse mix of applications.



The **IND145D** has been designed to be incorporated into manufacturing and routine maintenance programmes where the highest standards are essential.

It has an internal tank length of 1600mm, allowing thorough cleaning of elongated components such as oil filters, valves, tubes and many more.

The easily operated digital control allows the cycle time to be programmed up to 59 minutes, and the temperature up to 80°C.

### Standard Features:

- Digital control for time and temperature
- Stainless steel lid and basket
- Fluid level sensor
- 3 year warranty
- Basket shelf

### Optional accessories:

- Heated rinse tank
- De-I station
- Wheeled stand
- Comprehensive service contracts



# IND145D

## 145Litre Ultrasonic Cleaner

Construction Case	304 Stainless Steel
Construction Case	304 Stainless Steel (2mm)
Control	Digital (Time and Temperature)
Overall Dimensions	1750 x 450 x 475mm (WxDxH)
Tank Dimensions	1600 x 300 x 300mm (WxDxH)
Basket Dimensions	1185 x 285 x 235mm (WxDxH)
Capacity	145Litres
Ultrasonic Power	1500W RMS 3000W Peak to Peak
Ultrasonic Power (per litre)	12.5W/Litre
Operating Frequency	30 - 40KHz
Maximum Heating Capacity	Ambient - 80°C
Heater Power	1500W
Timer	0 - 59 minutes
Mains Connection	220 - 240V (50 - 60Hz)
Drain Outlet	¾" BSP Lockable drain valve
Lid	Stainless Steel
Basket	Stainless steel
Lockable Wheeled Stand	Optional
Warranty	3 Years



Product code: F0037901 (May 2015)



Eastgate Business Park  
Wentloog Avenue  
Cardiff CF3 2EY  
United Kingdom

Tel: +44 (0) 845 330 4236  
Fax: +44 (0) 845 330 4231  
Email: [admin@ultrawave.co.uk](mailto:admin@ultrawave.co.uk)  
Web: [www.ultrawave.co.uk](http://www.ultrawave.co.uk)