

# IND235D

## 235Litre Ultrasonic Cleaner

The **IND235D** is an Industrial grade ultrasonic cleaner for cleaning and processing larger components. Combining high performance transducers and a robust stainless steel tank, this 235Litre tank delivers excellent reliable performance across a diverse mix of applications.



The **IND235D** has been designed to be incorporated into manufacturing and routine maintenance programmes where the highest standards are essential.

It has an internal tank length of 1300mm, allowing thorough cleaning of elongated components such as oil filters, valves, tubes and many more.

The easily operated digital control allows the cycle time to be programmed up to 59 minutes, and the temperature up to 80°C.

### Standard Features:

- Digital control for time and temperature
- Stainless steel lid and basket
- Fluid level sensor
- 3 year warranty
- Basket shelf

### Optional accessories:

- Irrigation system
- Wheeled stand
- De-I station
- Comprehensive service contracts



# IND235D

## 235Litre Ultrasonic Cleaner

Construction Case	304 Stainless Steel
Construction Case	304 Stainless Steel (2mm)
Control	Digital (Time and Temperature)
Overall Dimensions	1525 x 600 x 600mm (WxDxH)
Tank Dimensions	1300 x 450 x 400mm (WxDxH)
Basket Dimensions	1285 x 435 x 335mm (WxDxH)
Capacity	235Litres
Ultrasonic Power	2000W RMS 5600W Peak to Peak
Ultrasonic Power (per litre)	8.5W/Litre
Operating Frequency	30 - 40KHz
Maximum Heating Capacity	Ambient - 80°C
Heater Power	4000W
Timer	0 - 59 minutes
Mains Connection	400 - 415V 3Phase + N + E
Drain Outlet	¾" BSP Lockable drain valve
Lid	Stainless Steel
Basket	Stainless Steel
Wheeled Stand	Optional
Warranty	3 Years



Product code: F0044701 (January 2015)



Eastgate Business Park  
Wentloog Avenue  
Cardiff CF3 2EY  
United Kingdom

Tel: +44 (0) 845 330 4236  
Fax: +44 (0) 845 330 4231  
Email: [admin@ultrawave.co.uk](mailto:admin@ultrawave.co.uk)  
Web: [www.ultrawave.co.uk](http://www.ultrawave.co.uk)